



Recycle bin

Product code: Bin01

Overview

The Skipper recycle bin is a robust and durable attachment for multi-purpose waste and recycling use. Up to two recycle bins can attach to the Skipper post & base system via its collar to create a fully free-standing safety & recycling station. The bins can also be attached to walls, magnetic surfaces, glass and high gloss surfaces, trees, posts and many more via the Skipper wall & magnetic receiver clips, suction pad holder/receivers and cord strap clips.

Product Specifications

Width: 338mm 13.3"	Height: 194mm 7.6"
Depth: 376mm 14.8"	Weight: 1.1kg 39.2oz

Key selling points

- Versatile design allows the recycle bin to attach to almost any surface
- Available in a range of lid colours (orange, green, red, blue, silver)
- Lightweight, durable design
- Internal grab mechanism to neatly hold all standard bag types

Key features

- Connects to the post & base collar, cord strap clip, wall clip and suction pad bracket
- Holds up to 15KG
- Supplied with stickers to designate general waste or recycling use

2 recycle bins can be attached to the Skipper post and base system via the post & base collar



Product FAQs

Q. What types of bag should be used with the recycle bin?

A. You can use any standard sized bag (simply lift the outer and inner lid and tuck the bag into the groove).

Q. What should I use the bin for?

A. The bin is designed to be used in a range of sectors including cleaning & hygiene, utilities, facilities management and construction (up to 15KG weight).

Q. Why should I choose a sack holder?

A. The Skipper sack holder offers a great waste management solution. As the sack is opened, you can clearly see its contents which aids effective waste separation and combats the growing challenge of contamination.